


Air/water/tank 6kw Split Heat Pump

User's Manual



➡ Before operating this product, please read the this manual carefully and keep it for future reference.

Catalogue

Before use

1

1. List of accessories	1
2. Safety precautions	2
3. Main components	5
4. Outlines and dimensions	7
5. Working principles	9
6. Specifications	9
7. Exploded view	11
8. Main components - Water pump	14
8.1 Wiring	14

Installation

15

1. Installation methods	15
2. Installation of the indoor unit	18
3. Installation of the outdoor unit	19
3.1 Installation notes	19
3.2 Installation	20
4. Wiring	21
4.1 For the installation of the Power cable between indoor and outdoor unit	21
4.2 Different wiring of 6kW electric heater	22
5. Refrigerant pipe connection	24
6. Water pipe connection	27
7. Installation of the kits	29
7.1 T/P valve	29
7.2 Automatic exhaust valve	28
7.3 Water pressure gauge	29
8. Water temperature sensor	31
9. Air purging of water system	32
10. Pre-Start up	34
10.1 Check before pre-start up	34
10.2 Pre-start up	34

Use 35

1. Introduction of wired controller	35
2. Operation on wired controller	36
3. Error code	39
4. Electric heating	41
4.1 1.7KW electric heating	41
4.2 6KW electric heating	41

Service and maintenance 43

1. Attention	43
2. Service	44
2.1 Indoor unit	44
2.2 Outdoor unit	44
3. Maintenance	45
3.1 Cleaning of water filter	45
3.2 Cleaning of heat exchanger	45
3.3 Gas charging	45
3.4 Antifreeze in winter	46
4. Troubleshooting	47

Wiring diagram 49

Before use



Attention









Thank you for choosing the product. In order to operate this product well and to prevent accidents due to misoperation, please read carefully this user manual before carrying out any installation or operation. Please pay special attention to the warning, prohibition and attention instructions. We will continuously upgrade this user manual for better service !

1. List of accessories



The accessories below are delivered together with the product .

Please check in time. If there is any shortage or damage, please contact local distributor.

【INDOOR UNIT】

Name	Quantity		Remark
User Manual	1 piece		Instruction of installation and operation
Rubber Absorber	3 piece		To be installed under the bottom of the indoor unit, for absorbing the vibration of indoor unit
One Way Valve	1 piece		To be installed on city water inlet
T/P Valve	1 piece		To be installed to connector for T/P valve
Water Pressure Gauge	1 piece		To be installed to connector for water pressure gauge
Automatic Exhaust Valve	1 piece		To be installed to connector for automatic exhaust valve
Connector (3/4" to 1/2")	1 piece		Connect to automatic exhaust valve
Sealing O-ring	2 piece		For sealing the connect of T/P valve and water pressure gauge

【OUTDOOR UNIT】

Name	Quantity		Remark
Installation Bracket	2 piece		For mounting outdoor unit to the wall
Rubber Absorber	4 piece		For absorbing the vibration of outdoor unit

Before use

【Symbol description】

The following symbols are very important. Please be sure to understand their meaning, which concerns the product and your personal safety.



Warning




Caution




Prohibition


2. Safety precautions




This appliance is not intended for use by persons, including children, with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.




The installation, dismantlement and maintenance of the unit must be performed by qualified personnel. It is forbidden to do any changes to the structure of the unit. Otherwise injury of person or unit damage might happen.



Make sure the power supply to the heat pump unit is off before any operations are done on the unit. When the power cord gets loose or is damaged, always get a qualified person to fix it.




Be sure to read this manual before use.




The power supply to the unit must be grounded.


Before use




Use a dedicated socket for this unit, otherwise malfunction may occur.




Don't run the heat pump unit with water temperature lower than 25°C.




Before taking shower, please always add a mixture valve before water tap and set it to proper temperature.



Keep the unit away from the combustible or corrosive environment.




Water or any kind of liquid is strictly forbidden to be poured into the product, or may cause creepage or breakdown of the product.




When running the unit, never cover the product with clothes, plastic cloth or any other material that block ventilation on the product, which will lead to low efficiency or even non-operation of this unit.

Before use




Be aware finger might be hurt by the fin of the coil.




Please select the correct fuse or breaker as per recommended. Steel wire or copper wire cannot be taken as substitute for fuse or breaker. Otherwise, damaged maybe caused.




When the power cord gets loose or is damaged, always get a qualified person to fix it.



Do not touch the air outlet grill when fan motor is running.



Please mind that when the unit works under room temperature control mode, it may not supply sanitary hot water with enough high temperature.




It is mandatory to use a suitable circuit breaker for the heat pump and make sure the power supply to the heater corresponds to the specifications. Otherwise the unit might be damaged.

Before use


3. Main components

【Indoor unit】


Outside



Top




Inside



NO.	NAME
1	Right Panel
2	Handle
3	Wired Controller
4	Front Panel
5	Thermostat 1
6	Small front panel
7	Decorative Panel
8	Left panel
9	High Temperature Water Outlet
10	City Water Inlet
11	Shower Coil Water Inlet
12	Water from Floor Heating/Radiator
13	Medium Temperature Water Outlet
14	Water Pressure Gauge
15	Power Supply
16	Quick Connector for Power Cable to Outdoor Unit





NO.	NAME
17	Quick Connector for Piping Kit
18	Automatic Exhaust Valve
19	T/P Valve
20	Water Outlet to Radiator
21	Water Outlet to Floor Heating
22	P.C.B
23	Anode Rod
24	Thermostat 2
25	1.7KW Electric Heater 230V/50Hz/1PH
26	6KW Electric Heater 400V/50Hz/3Ph(can be 230V/50Hz/1ph by change the wiring)
27	Heat Exchanger
28	Water Pump
29	Temperature Sensor 2
30	Temperature Sensor 1
31	Drainage

【Outdoor unit】




4. Outlines and dimensions

【Indoor unit】




Unit:mm



Before use

【Outdoor unit】

Unit:mm




Liquid pipe O.D. ϕ 6.35(1/4")

Gas pipe O.D. ϕ 12.7(1/2")

Before use

5. Working principles



6. Specifications

Indoor unit			
Model number		AW 6-IQC-IOU-V5	
Power supply		230V/50Hz/1PH	
1.7KW Electric Heater		230V/50Hz/1PH	
6KW Electric Heater		400V/50Hz/3PH or 230V/50Hz/3PH	
Water side Heat Exchanger	Type		Tube-in-tube heat exchanger
	Water pressure drop	Kpa	30
	Piping connection	Inch	G3/4"
	Water head	M	6
	Rated water flow	m ³ /h	1.0
Max. Water Temp.		°C	75
Tank Volume		L	200L
Refrigerant	Indoor unit		R410A
	Piping kits		R410A
Net dimension		mm	600×600×1580
Packing dimension		mm	655×640×1730
Net weight		Kg	120
Gross weight		Kg	135

Before use

Outdoor unit			
Model number		AW 6-IQC-IOU-V5	
Power supply		230V/50HZ/1PH	
Refrigerant volume		R410A	
Heating capacity		Btu/h	7165-20472
		W	2100-6000
Input power (Heating)		W	500-1500
Input current (Heating)		A	2.2-6.5
C.O.P		W/W	3.3-4.2
Compressor	Type		Inverter rotary
	Quantity	Pcs	1
Fan	Type		Axial
	Quantity	Pcs	1
	Airflow	M ³ /h	1750
	Input power	W	85
Air side Heat Exchanger	Type		Tube-Fin
	Face area	M ²	0.395
	in/Fins-Row		2 Rows-14
	Tube Diameter	Inch	3/8"
Noise		DB(A)	46
Net dimension		mm	780×255×590
Packing dimension		mm	920×340×600
Net weight		Kg	33
Gross weight		Kg	36

Technical specification	
Ambient temperature range in heating	-25-45℃
Outlet water temperature range in heating	25-52℃
Max refrigerant pipe length (single return)	10m
Max height difference between indoor and outdoor unit	5m
Refrigerant pipe dimension	Liquid pipe OD12.7(1/2"), Gas pipe OD pipe 6.35(1/4")
Connector	Quick connector

Installation advice	
Max allowable water pressure	0.7 Mpa
Max setting temperature	52℃
Max outlet water temperature at ambient temperature -15℃	52℃

Note:


Heating condition: Water in/out temperature: 30℃/35℃, ambient temperature: DB/WB 7/6℃.

The specifications are subject to change without prior notice.

For actual specifications of the unit, please refer to the specification stickers on the unit.

7. Exploded view

【Indoor unit】




Before use

No.	Name	Quantity	No.	Name	Quantity
1	Left panel	1	26	Electrical box	1
2	Handle	5	27	4 bit terminal block	1
3	Wired controller	1	28	3 bit terminal block	1
4	Front panel	1	29	AC contactor	1
5	Thermostat knob	2	30	Controller	1
6	Decorative panel	1	31	Water pump	1
7	Small front panel	1	32	Water pump bracket 1	1
8	Stainless steel coil1	1	33	Water pump bracket 2	1
9	Thermostat	2	34	Tube in tube heat exchanger	1
10	Bracket of rubber base	1	35	T type three way valve	1
11	Water pressure gauge	1	36	Brass connector	6
12	T/P valve	1	37	Middle plate	1
13	Cable gland PG16	1	38	G3/4" Copper nut	3
14	Cable gland PG21	1	39	Water tank	1
15	G1/2" Copper nut	3	40	Electric heater	1
16	Automatic exhaust valve	1	41	Thermostat bracket	1
17	Rubber base	1	42	Back panel	1
18	Top panel	1	43	Right panel	1
19	Connector	7	44	Stainless steel coil 2	1
20	Connector adaptor 1	1	45	Ball Valves	1
21	1/2" gas valve	1	46	Bottom plate	1
22	1/4" liquid valve	1	47	Rubber feet	4
23	Connector adaptor 2	1	48	Plastic cover	3
24	T type three way valve 2	1	49	Connector adaptor for water pressure gauge	1
25	Copper pipe	3			

Before use

【Outdoor unit】



NO	Name	NO	Name
1	Top panel	14	Four-way valve
2	Control box connect panel	15	Four-way valve coil
3	Bulkhead	16	Sensor
4	PFC transducer	17	Capillary
5	Condenser	18	Filter
6	Condenser Heater	19	Right plate
7	Compressor	20	One way valve
8	Bottom plate	21	Valve
9	Handle	22	Big Handle
10	Front panel	23	Gas Connector
11	Pressure	24	Liquid Connector
12	Axial Fan With External Rotor	25	Valve plate
13	Control system		

Before use

8. Main components - Water pump

Temperature range

Ambient temperature: 0°C to 40°C


Media temperature: +2°C to 95°C

8.1 Wiring



Danger! Risk of electrocution.

- Have all electrical work carried out by qualified electricians only.
- Disconnect the electrical circuit and lock it to prevent accidental start-up.
- Check to make sure the power is turned off.




Installation



The installation of the product should be handled by professional installer or under their instructions.

【Tools】

Most people already have the tools needed for installation: spirit level, pencil, crosshead screwdriver, drill 8mm. concrete drill bit, detection drill, square, tape measure or ruler, tape width 65 mm, hole saw about 80mm (deviation in size may occur), knife and two adjustable spanners or pliers (and possibly torque wrench).













1. Installation methods

Sanitary hot water, floor heating hot water and radiator heating hot water can all be get from the indoor unit. With its inbuilt 1.7kW and 6kW electric heater, it ensures its heating capacity in cold days and guarantees enough high temperature sanitary hot water.

By using a mixture water to mix high temperature sanitary hot water and medium temperature sanitary hot water together, it ensures the ideal temperature of sanitary hot water, as well as increases the amount of sanitary hot water.

Installation




Symbol	Name
	Mixture valve
	Water pump
	Filter
	T/P Valve
	One way valve
	Automatic Exhaust Valve
	Water Pressure Gauge
	Shutoff valve
	Three-way valve


Installation

If bivalent valve is needed for radiator system, please connect it to the system as shown below:

1. With bivalent valve and radiator system only




2. With bivalent valve, radiator system and also floor heating system



2. Installation of the indoor unit

【Installation notes】

- A. The indoor unit can be located in a room, corridor, balcony, garage or warehouse.
- B. Indoor unit should be placed on flat and solid ground.
- C. The unit is recommended to be put in a space close to water supply, and drainage.
- D. The outdoor and indoor unit should be placed close, to save the copper tube as well as the energy.
- E. The indoor unit shall be placed in dry and well-ventilated environment.
- F. Indoor unit mustn't be installed in an environment where volatile, corrosive or flammable liquid or gas exists.
- G. During the movement, please be careful to keep the unit vertically. If the unit is tilted by 30° , it may fall down and cause damage to itself or the porter.
- H. Don't expose the operation panel under direct sunshine.
- I. Enough space should be left around the indoor unit for further maintenance.




Installation

3. Installation of the outdoor unit

3.1 Installation notes

- A. The outdoor unit can be located in a room, corridor, balcony, and roof or hanged on the wall.
- B. Please don't install outdoor unit close to bedroom or living room, because there is some noise when it's running.
- C. The outdoor unit shall be placed in dry and well-ventilated environment.
- D. Outdoor unit mustn't be installed in an environment where volatile, corrosive or flammable liquid or gas exists.
- E. Please cover a protecting roof over the outdoor unit, lest ice or snow blocks the air inlet. Shield the unit from direct sunshine, rain or snow, but never cover the unit which will cause the bad ventilation.
- F. Please ensure there is drainage system around the location, to drain the condensated water under defrosting mode.
- G. Please don't install the indoor and outdoor unit in damp locations, otherwise it may cause short-circuit or corrosion of some components. The unit should be free from corrosive and moisture surrounding. Otherwise the lifetime of the unit might be shortened.
- J. When installing the unit in harsh climatic conditions, sub-zero temperatures, snow, humidity area, please raise the unit above the ground by about 20cm.
- I. When installing the unit, tilt it by 1cm/cm to left side of the unit (see from front), for better water drainage.
- J. Outdoor unit should be placed on flat and solid ground. When installing the outdoor unit, please ensure enough space around the outdoor unit, for better ventilation and maintenance. Please refer to the illustration below.




Installation

3.2 Installation




Please add rubber absorber under the outdoor unit, to reduce the vibration.

【A. On a concrete stand】




【B. On brackets on the wall】

1. Fix the bracket on the wall with expansion bolts.
2. Place the outdoor unit on the bracket. A rubber absorber is recommended to reduce the noise of the outdoor unit.
3. Fix the unit to the bracket.



The refrigerant piping and signal cable between indoor and outdoor unit should go through the wall by using a wall sleeve.

The hole should lean to outside a little bit (≥ 8 degrees), to avoid rain water or condensate water flow back to the indoor.



4. Wiring



【Precaution:】

1. The appliance shall be installed in accordance with national wiring regulations.
2. It is recommended to use a suitable circuit breaker for the heat pump and make sure the power supply to the unit corresponds to the specifications. Otherwise the unit might be damaged.
3. The power supply to the heat pump unit must be grounded.
4. Cable should be fixed tightly, to ensure it won't get loose.


4.1 For the installation of the Power cable between indoor and outdoor unit

Please connect the wiring between indoor and outdoor unit, by connecting the quick couples together.

Cable with quick couples is packed together with the piping kit.



Take off small handle in outdoor unit, connect the cable by connecting the quick couples together.





Connect the other end of the cable, to the quick connector on the top of indoor unit.

Installation

4.2 Different wiring of 6kW electric heater

1. The default wiring for 6kW heater is for 400V/50Hz/3Ph power supply. Following is how the heater is connected:



Please note: If the wire for this heater need to be changed, the replaced cable should be no smaller than 1.5mm².



Installation

2. If this heater need to work under 230V/50Hz/3Ph power supply, please change the wiring as following:

Note: the cable size should not be smaller than 2.5mm² under this application.




Installation

5. Refrigerant pipe connection

Please take the refrigerant pipe and accessories from the carton box of piping kit.

When insulating the refrigerant pipe, please insulate each pipe separately (refer to figure 1 below), don't insulate the refrigerant pipes together (refer to figure 2 below).



【Precaution】

The installation kit consists of two gas-filled pipes, drainage hose, sealant, diffusion tape, 2 pipe insulation sections, cable ties and electrical cable with connector arrangement for connecting the indoor unit to the outdoor unit.

Note that the drainage hose must only be used for air/air heat pumps and therefore not for air/water.



NOTE: Do not remove the plastic plugs on the pipe sections until the installation of the pipes has begun.

【Holes】



Start by drilling with the detection drill to check that there are no obstacles in the way and that the hole on the outside will be correct. Holding the detection drill sideways, feel inside the wall if there is anything in the way around the detection drill's hole.

If there is nothing obstructing the detection drill, the wall bracket can be fitted and the hole (about 80mm) drilled. Check the dimension or the supplied wall bushing.

Set the drill at low speed to prevent a build-up of heat and the saw teeth becoming “sticky”. It is also a good idea to pre-drill with a 12-15mm bit so that any chips in the wall can run out.

Installation

【Installation】



Start the installation of the pipe kit at the indoor unit and then straighten out the pipes gradually. On the ends of the pipe lengths (installation kit) there are two loose screw connections. There are two fixed nipples on the units' pre-fitted pipe sections. The pipe lengths' loose screw connections must be screwed to the units' fixed nipples. These cannot be installed incorrectly, but it is very important when connection that the nipple is held in a fixed position, while the second spanner screws on the coupling.

Now connect the pipes from the installation kit with the fixed nipples on the indoor unit couplings. Start by threading together all the screw connections by hand. Then use the spanners to tighten the coupling. Complete the connection without stopping (a hissing sound may be heard), use a counterhold and tighten the coupling securely.

Tightening min. torque 18 Nm. Use a torque wrench when in doubt.

Never under any circumstances tighten the fixed nipples with the spanner. Use one of the spanners only as a counterhold when connecting. It should be noted that if you do not use a counterhold, you risk turning the nipples on the indoor unit too much and rendering them useless. The couplings have to be tightened around 24 h after the installation has been completed.



IMPORTANT:

Note that the pipes in the installation kit are filled with gas and must not be cut under any circumstances.


The plastic plugs on the ends of the pipe must not be removed until the pipes are to be connected. If the pipes are bent and causing leakage, the couplings must be loosened so that the non-return valves close.

Installation

【Pipe routing】

IMPORTANT:

Continue the pipe from the indoor unit to the outdoor unit and connect the pipe fittings in the same way. The radius at pipe bends must not be less than 15 cm. Use a cardboard template to check this. Run the power cord along with the pipes. Create the bends gradually and carefully. You must not bend the pipe straight across, for example, to the edge of the hole in the wall.



【Connecting the installation kit】

On the ends of the pipe lengths (installation kit) there are two loose screw connections.

There are two fixed nipples on the outdoor unit's pre-fitted pipe sections. The pipe lengths' loose screw connections must be screwed to the units' fixed nipples.

These cannot be installed incorrectly, but it is very important when connecting that the nipple is held in a fixed position (counterhold), while the second spanner screws on the coupling.

Connect the pipes from the installation kit with the fixed pipes mounted on the outdoor unit. Start by screwing together all the screw connections by hand.



Then use the spanners to tighten the coupling. Complete the connection without stopping (a hissing sound may be heard), use a counterhold and tighten the coupling securely.



Never under any circumstances tighten the fixed nipples with the spanner. Only use the spanner as a counterhold when connecting. It should be noted that if you do not use a counterhold, you risk turning the nipples on the outdoor unit too much and rendering them useless. Check and tighten the couplings about 12-24h after installation.

Installation

Check the couplings for leaks by applying some soap and water. Check for bubbles.

Check the seals and tighten the couplings again 12-24 hours after installation. Check for leaks by wetting with soapy water. Also check the connections at the indoor unit. If no bubbles appear, the couplings are properly connected and tightened!



6. Water pipe connection

After installing the unit, please connect the water inlet and outlet pipe according to the local instructions. Please carefully select and operate the water pipe.

After connection, the water piping should be pressure tested, cleaned before use.

【Water filling】

▲ One way valve:


One way valve must be installed to water filling connector, to avoid back-flow of water when water supply stops or water pressure not enough (one way valve is packed with the unit).

▲ Filter:

A filter (20 mesh/cm²) should be installed at the water inlet of water tank as well as that of indoor unit, to avoid sediments and guarantee water quality.

▲ Ball valve:


A ball valve is recommend for easy operation of drainage or filter cleaning.




Installation

【Connect of drainage pipe】


When the tank need to be drained, please do as per following instruction:



1. Take off the front panel (please take care about the wires in between. Please disconnect all cables in between before the front panel fully opened).



2. A soft pipe and ball valve have already been connected to the tank. Please pull it out from the unit.



3. Drain the water to drainage system of the house, and open the ball valve to drain out all water inside the tank. Please extend the drainage pipe by connecting another water pipe, if the distance between the unit and drainage system is long.

【Insulation】

All pipes running hot water should be well insulated. The insulation must be tied up tightly without gap (But please don't wrap up the check valve for future maintenance).



Please ensure enough water pressure to deliver the water to the required height. If the water pressure is not enough, please add water pump to increase the pumping head.


Installation

7. Installation of the kits in the accessories

7.1 T/P valve

In order to protect the water tank from too high pressure or temperature, please install the T/P valve packed together with the unit, to the system:


1. Take the T/P valve out from accessories bag.
2. Add a sealing o-ring in the accessories bag to the T/P valve.
3. Connect T/P valve to the connector marked out for T/P valve on top of the unit, tighten it with wrench.
4. Connect a drain pipe to T/P valve, in case water release from this valve under too high pressure or temperature.



7.2 Automatic exhaust valve

Automatic exhaust valve is used to pumping out exhaust gas inside the water system. Please install it to the unit as followings:

1. Take automatic exhaust valve and connector(3/4" to 1/2") out from accessories bag.
2. Connect the connector (3/4" to 1/2") to the valve, and tighten it with a wrench.
3. Apply the sealing tape to the thread of the connector clockwise at least four turns.
4. Connect it to the connector for automatic exhaust valve on top of the unit.




Installation

- ▲ After install the automatic exhaust valve into the right position, please loosen the small screw cap on the top of the valve in order to ensure the gas can be drained away.
- ▲ When the valve is blocked, do fasten the small screw cap on the top of the valve and then remove the valve and clean it. After done, do install the valve back to the top of water tank and loosen the small screw cap again.

7.3 Water pressure gauge

For easy checking of water pressure, please connect the water pressure gauge to the unit:

1. Take it out from the accessories bag.
2. Add sealing o-ring to the pressure gauge.
3. Connect to connector for pressure gauge on top of the unit.



Installation

8. Water temperature sensor

The temperature sensor is default placed in "temperature sensor 1" (refers page 5), but if needed, it can be moved to the position of "temperature sensor 2" (refers page 5), as follows:

1. Screw off the cable fixture on plastic cover for "temperature sensor 1", and pull out the temperature sensor. Please install the cable fixture and its rubber o-ring back to the cap, for future demands.



2. Remove the plastic cover on the position of "temperature sensor 2" for installing the temperature sensor on the water tank, screw off the plastic nut and remove the "O" shape rubber ring.



3. Pass the temperature sensor through the plastic nut and reinstall the "O" shape rubber ring.




4. After the temperature sensor pass through the plastic cover and completely insert into the temperature sensor 2 hole on the tank, please screw tightly the plastic nut.



Installation

9. Air purging of water system



Symbol	Name
	Mixture valve
	Water pump
	Filter
	T/P Valve
	One way valve
	Automatic Exhaust Valve
	Water Pressure Gauge
	Shutoff valve
	Three-way valve

Installation

After finishing the installation, please refer the application illustration on page 34 and proceed with the following steps to discharge the air in the system:

Evacuation of water tank

1. Close ball valve 2 and open ball valve 4,11,14.
2. Open ball valve 3 and 1, tap water enters into the water tank till water flows out from ball valve 4,11,14. Close ball valve 4,11,14.
3. The air purging valve and T/P valve discharge the air till water comes out from air purging valve and T/P valve without any air bubble.

Evacuation of shower coils in water tank

1. Close ball valve 7 and 10.
2. Open ball valve 2,5,6,8,9, some water enters into the shower coils in water tank till water flows out from ball valve 6 and 9. Close ball valve 6 and 9.
3. Open ball valve 7 and 10, till water comes out from two sanitary hot water outlets.

Evacuation of floor heating and radiator system

1. Open ball valve 1.
2. Open ball valve 12,13,15,16, to fill the water in the whole end system.
3. Use the air purging valve in the end system(floor heating and radiator system) to discharge the air till water comes out from the air purging valve.
4. Keep the ball valve 12,13,15,16 open. Close the air purging valve in the end system.

Note: During the whole process of air purging and after air purging is finished, keep the ball valve 1 open, and the ball valve of drainage inside the water tank should be closed.

10. Pre-Start up

10.1 Check before pre-start up

Before start-up, please check the following items:

- A. Check if the water pipes are connected well and if there is any leakage;
- B. Make sure the water supply valves are open and the water flows smoothly;
- C. Check if the power cable is connected well and properly grounded, and if the cable is broken or not.
- D. Make sure the indoor and outdoor units have been installed in a flat and solid location.
- E. Check if the power supply corresponds with the specifications on the label.
- F. In cold area, please ensure the supply water flow is smooth without freezing.
- G. Check if the refrigerant pipe and water pipe are well insulated.



If everything above is OK, the unit can start up.
If any of them fails, please fix it.


10.2 Pre-start up

- A. When the installation of unit is completed, water system pipes are well connected and air purging is done, no leakage or other problems, the unit can be powered to start up.
- B. Turn on the unit, press the on-off button on the operation panel to start the unit.
Please check carefully if there is some abnormal noise or vibration, or the display of wired controller is normal or not.
- C. After the unit is working properly for 10 minutes, without any problem, then the pre-start up is completed; If not, please refer to the Service and Maintenance chapter in this manual to solve the problems.
- D. Keep the unit running check if the supply water temperature is the same as shown on the wired controller. If the water is not heated properly, please refer to "Trouble Shooting" to check the possible causes.



It is suggested not to run "heating" or "hot water" mode, when ambient temperature is over 32 °C, otherwise unit may go into protection mode easily.

1. Introduction of wired controller




Display	Meaning	Function
	Heating	When the unit works in heating mode, is ON.
	Cooling	When the unit works in cooling mode, is ON.
	Hot water	When the unit works in hot water mode, is ON.
	Defrosting	When the unit works in defrosting, is ON.
	Key lock	When buttons are locked, is ON.
	Parameter setting	When parameter setting is activated, is ON.
	Value or code	To display temperature, timer, parameter, error code and so on.
	Time	The unit will clear its clock time when power failure happens.
	Water temperature	When water temperature mode is activated, is ON.
	Set temperature	When changing the set temperature, is ON.
	Timer function	When timer function is activated, is ON.

2. Operation instruction

➔ Standby

The unit is standby when it is fed with power.


☆The unit will clear its clock time when power failure happens.
The customer needs to set time again.




➔ ON/OFF

When the unit is standby, press  to turn on the unit.


The unit will work in its last working mode.


Press  again to turn off the unit.

☆The unit will recover its latest working settings automatically after power failure.




➔ Mode selection

Keep on pressing  button to choose water temperature or air temperature as the set temperature. When water temperature works as the set temperature, **Water Temp.** is ON; When air temperature works as the set temperature, **Water Temp.** is OFF.







➔ Mode selection

Press  to choose the unit operation mode. It comes in the sequence:




Use


➔ Temperature setting

When the unit is ON, press  once, the set temperature increases by 1 °C ; press  once, the set temperature decreases by 1 °C. keep on pressing  or , the temperature can be increased or decreased by 5 °C.



When changing the set temperature, **Set Temp.** is ON.




➔ Parameter setting




When power is fed and unit is off, press  or  to choose target Parameter.


press **SET** to activate parameter setting process when parameter flickers. User can set its value with button  or ; Press **SET** again to confirm the setting work: otherwise the setting Value will not be saved, and the system will exit this parameter setting program automatically in 10 seconds, or by pressing.



Parameter 1
Parameter 1 indicates the local time. The time is always presented in the 24-hour system.



Parameter 2
This parameter has no function in this unit.




Parameter 3
Parameter 3 indicates the duration time for back light. It can be set to 00, 10, 20, and 30. While 00 means the back light is always ON, and 10, 20, and 30 means the duration time for back light is 10 seconds, 20 seconds and 30 seconds.


Use

➔ Timer function

To set the ON timer, press button. ^{ON} turns on and blinks. Press to set the timer in hours, and to set the time in minutes. After it is done, press to confirm the ON timer setting and enter the OFF timer setting, with ^{ON} _{OFF} blinks. Set the OFF timer by pressing and . After this done, press to confirm the OFF timer setting, with ^{ON} _{OFF} shown on the operation panel, indicating that the timer setting is finished.




If the ON timer or OFF setting is not confirmed by pressing , the setting value is not saved. The timer setting can be cancelled by keeping on pressing , with fading from the operation panel.



▲Timer ON


Timer ON setting doesn't function when the unit is working. It will be activated when unit is turned OFF.



▲Timer OFF

Timer OFF settings only functions after the starts. It can be activated when the unit is turned ON.

➔ Key lock



When the unit is ON, press for 5 seconds, to lock all the buttons, with shows. Press for 5 seconds again, to unlock all the buttons.

3. Error code

Error Codes	Causes	Ways to check and remedies
E0	1.Wire connection between wired controller and PCB open or short-circuited.	1. Cheak whether the wire connection gets loose.Fasten it.
	2.Wired controller failure.	2.Change it.
E1	1.Wire connection between wired controller and PCB open or short-circuited.	1. Cheak whether the wire connection gets loose.Fasten it.
	2.Wired controller failure.	2.Change it.
E2	1.temp.sensor open or short-circuited.	1.Measure with a multimeter at 20K to check whether it is shirt-circuited or open.If yes,change it.
	2.temp.sensor resistance drifting.	2.Measure with a multimeter at 50K to check the sensor resistance. Take ambient temp.into consideration.If it isdrifting,change it.
	3.Temperature sensors not well connected to the wired controller.	3.Check whether the sensor connection gets loose. Fasten it.
F2	1.water inlet Temp sensor failure.	1. Check whether the sensor connection gets loose. Fasten it. 2. Wire connection between wired controller and indoor PCB open or short-circuited. 3. water inlet Temp sensor resistance drifting.
	2.water outlet Temp sensor failure.	1. Check whether the sensor connection gets loose. Fasten it. 2. Wire connection between wired controller and PCB open or short-circuited. 3. water outlet Temp sensor resistance drifting.
	3.Coil Temp sensor failure.	1、 Check whether the sensor connection gets loose. Fasten it. 2、 Wire connection between wired controller and indoor PCB open or short-circuited. 3、 Temp sensor resistance drifting. temp. sensor resistance drifting.
F1	Communication failure.	1、 Check whether port gets loose. Fasten it. 2、 Change the PCB. 3、 Change the outdoor PCB
F4	Compressor drive failure、 IPM failure、 IPM protection(overload)、 drive protection.	1.Check whether PFC transducer gets loose. Fasten it. 2.Change PFC transducer.
F3	Current or Voltage detector failure.	1.Change PCB
F5	EEPROM failure.	1.Check whether EEPROM gets loose.Fasten it. 2.Change EEPROM
F6	Too high coil.Temp in heating.	1.Cheak the water flow of the unit. 2.Too high ambient and water Temp.Reduce the set water Temp.

F6	Too high pipe Temp in cooling	1.Check the water flow of the unit 2.Too low ambient and water Temp.Increase the set water Temp.
	Over-current protection	1.Check the water flow of the unit. 2. Too high (low) ambient, and too high(low) set water Temp. Decrease or increase the set water Temp.
F7	Too high or too low voltage	1.Check the voltage of the power supply. 2.Change the outdoor PCB
F8*	Pressure switch failure	1.Check the pressure of the system 2.Change the pressure switch
F9	EEPROM failure	1.Check whether EEPROM gets loose. Fasten it. 2.Change outdoor EEPROM
Fb	Ambient temp. sensor failure	1、 Check whether the sensor connection gets loose. Fasten it.
	Pipe temp. sensor failure	2、 Wire connection between wired controller and PCB open or short-circuited.
	Compressor discharge temp. sensor failure	3、 Temp sensor resistance drifting.
Fc*	System protection caused by too high(low) pressure	1. Measure the high (low) pressure switch with a multimeter to check whether it is short-circuited or open. If yes, change it. 2.Check the water flow of the unit.
Fd	System protection caused by the ambient Temp.	1. Check the ambient Temp sensor. 2. Check whether the ambient Temp is too high(low) for working (Ambient lower than -1℃ or higher than 65℃ in cooling, lower than -25℃ or higher than 33℃ in heating).

Difference between F8 and Fc*:

System Pressure Protection

In compressor's operation, when system pressure rise too high and pressure switch turns off, (in system's normal operation, pressure switch keeps on), the controller will lower compressor's running speed by 1Hz/s until pressure switch reconnects. Meanwhile, it records the compressor's current running speed, and takes the value one level lower as the maximum speed. This limit will be released automatically after compressor keeps on running for 2 hours. However, if during this process, similar pressure protection happens again, the controller will records the new running frequency and takes 1 level lower than this new frequency as the maximum speed. And it will release this protection in 2 hours since the time when this new protection happens. If compressor is off, but pressure switch is disconnected for 5 seconds, the controller will judge it as "Pressure Switch Failure" and relevant error code will be shown in wired controller.

For check whether the system have this pressure switch failure or protection is due to hardware failure, we can do like this:

- 1.Turn the unit off, and cut the power. Leave the unit without power for 10 minutes.
- 2.Power up the unit.
- 3.If F8* comes once after power the unit, then it is for sure that it is the pressure switch itself, or the cable loosen that cause F8* failure.
- 4.If not, then it is for sure that the refrigerant system working abnormal, that caused this high pressure switch failure.


4. Electric heating

This unit has included two electric heaters inside. Two electric heaters are used to keep the water temperature when heat pump capacity is not enough or heat pump fail to work, as well as heat the water up more rapidly when water temperature is low.

4.1 1.7KW electric heater

1. 1.7kW electric heater is manually control only. It is not connected with controller of heat pump.
2. Power supply is 230V/50Hz/1Ph, and temperature setting range is 30~75°C.
3. This heater is mainly used to get high temperature sanitary hot water or get hot water faster.
4. If heat pump fails to work, this heater can still work.

Operation knob for 1.7kW heater is on front panel, for easy access. Please refers to following picture.




4.2 6KW electric heater

1. 6kW heater is connected to indoor PCB, and under the control of the unit.
2. Power supply is 400V/50Hz/3Ph, and set temperature range is 30~75°C. If need connect this heater to 230V/50Hz/3Ph, please refer to chapter "Different wiring of 6KW electric heater".
3. On top of the indoor unit, there is a power cable for this heater. Please connect it to a breaker which is enough for 6kW.
4. 6kW is mainly used as an auxiliary heating for house heating.
5. When heat pump fails to work, please set the thermostat of this heater to a correct setting, so it can work as a back-up heater.
6. Please pay special attention to the temperature setting of this heater. If the set value of this heater is higher than heat pump temperature setting, it may happen that main heat would be generated by electric heater, instead of heat pump.

Please do as follows to get access to thermostat for 6kW electric heater:


Use

1



Take off the screw of access door on front panel.

2



Turn the thermostat knob to set temperature.

3



Put the access door back and fix it with screw.



- This electric heater is set to turn on when water temperature drops to 30°C, in case heat pump capacity is not enough in critical weathers or heat pump fails to work.
- It can also be set manually to higher temperature when needed. However please always make sure to set it to lower temperature than heat pump set temperature, otherwise the heater will turn on before the heat pump starts to work, and the system will not work efficiently.

Service and maintenance

1. Attention



- A. The user mustn't change the structure or wiring inside the unit.
- B. The service and maintenance should be performed by qualified and well-trained technician. When the unit fails to run, please cut off power supply immediately.
- C. The smart control system can automatically analyze various protection problems during daily use, and display the failure code on the controller. The unit may recover by itself. Under normal operation, the pipings inside the unit don't need any maintenance.
- D. Under normal running, the user only needs to clean the surface of the outdoor heat exchanger per month or quarter of a year.
- E. If the unit runs in a dirty or oily environment, please clean the outdoor heat exchanger and heat exchanger by professionals, using specified detergent, to ensure the performance and efficiency of the unit.
- F. Please pay attention to the ambient environment, to check if the unit is installed firmly, or if the air inlet and outlet of the outdoor unit is blocked or not.
- G. Unless the water pump is damaged, no service or maintenance should be taken to the water system inside the unit. It's recommended to clean water filter regularly or change it when it's very dirty or blocked.


Service and maintenance

2. Service

2.1 Indoor unit

Service on indoor unit as follows: (this operation must be done by qualified personnel)


1. Cut off the power supply
2. Remove the front panel (Be care about the cables in between)
3. Check the electric part



2.2 Outdoor unit

Service on outdoor unit as follows: (this operation must be done by qualified personnel)

1. Cut off the power supply
2. Remove the top cover
3. Take off the electronic box cover
4. Check the electric part



3. Maintenance

3.1 Cleaning of water filter

The water filter should be cleaned according to the manual of water filter, to ensure the water flow of the water system. It is recommended to be cleaned once in the first month, and then, once half a year.

3.2 Cleaning of heat exchanger

Heat exchanger should be cleaned once half a year, because after long term running, gap between the fins of heat exchanger may be clogged up by dust, leaves, plastic films or papers, which will affect the efficiency of heat exchange, please clean the heat exchanger as follows:

- A. Use a vacuum cleaner to clean the surface of the fins, to get rid of the dust or other rubbish.
- B. Use a soft nylon brush to clean the fins, rinse by water at the same time (please don't rinse with high water pressure). If the outdoor unit is located in an oily place and is hard to clean, please ask for professional service to clean it.
- C. After cleaning, please leave the unit at a shady and well-ventilated environment to dry the surface of the unit.
 - ①. Avoid splashing water to the electric part when cleaning.
 - ②. Avoid touching the sharp fins when cleaning, or they may cut your skin. It's recommended to wear rubber gloves before cleaning.
 - ③. The fins of heat exchanger are soft, please don't wipe strongly with hard object, or it may damage the fins.
 - ④. If the unit is working in a salty environment, please clean the heat exchanger more often.
 - ⑤. If the fins have corrosion in surface, please move the unit to a better environment.

3.3 Gas charging

The refrigerant plays an important role in delivering energy in cooling or heating. Insufficient refrigerant affects directly efficiency of cooling and heating. Please pay attention to the following before adding refrigerant:

- A. The work should be done by professionals
- B. Please make sure the copper pipe has no leakage before gas charging. If the copper pipes has leakage, please repair or change the pipes firstly.
- C. Don't add too much refrigerant than required, or it may cause a lot of failures, such as high pressure and low efficiency.
- D. This system uses R410A refrigerant, whose pressure is about 1.6 times than that of R22, so never use R22 or other refrigerant to replace R410A.
- E. There must be no air in the refrigerant circulation, because the air will cause abnormal high pressure, which will damage the gas piping and lower heating or cooling efficiency.
- F. If the refrigerant leaks in indoor environment, please ventilate the room.

Service and maintenance

G. Copper pipe must be used for gas pipe. Never use iron pipe, aluminium pipe or alloy pipe.

Gas pipes sizes:

Outer dimension (mm)	Thickness (mm)
ϕ 6.35	0.65
ϕ 12.7	0.75

3.4 Antifreeze in Winter

In order to avoid the water inside unit freeze and damage the unit , please don't turn off the unit very often, keep it working or standby when the ambient temp. is below 0°C.

Service and maintenance

4. Troubleshooting

Failure	Cause	Solution
Unit can't start up	1. No power supply	1. Check the power supply
	2. Fuse is broken or circuit breaker is disconnected	2. Check if it's open circuit or if the motor coil is earthed. Then change a fuse and reset the breaker, check if the circuit is stable or the connection is well.
	3. Some kind of protection works	3. Check which protection is working, and clear the protection, then restart the unit.
	4. Wiring is loose	4. Check the wire connection and tighten the screws on the terminal
	5. compressor fails	5. Change a compressor
Fan fails to run	1. Fan motor wire loose	1. Check the wire connections.
	2. fan motor failure	2. Change fan motor.
Low heating performance	1. The coil fins are very dirty	1. Clean the evaporator coil
	2. Air inlet is blocked	2. Remove any object that blocks the air circulation of the unit.
	3. Insufficient of refrigerant	3. Inspect the unit for leakage and fix it if any. Discharge all refrigerant and charge the unit again with correct amount.
Too high noise from the water pump, or no water flow when the water pump is running	1. Lacking of water in water system	1. Check the water filling device. Fill the system with enough water.
	2. Air exists in water system	2. Purging the air out.
	3. Valves in water system are not completely opened	3. Check all the valves to ensure they are fully opened.
	4. Water filter is dirty or blocked	4. Clean the water filter
Too high compressor discharge pressure	1. Too much refrigerant	1. Discharge all refrigerant and charge the unit again with right amount.
	2. Air exists in refrigeration system	2. Discharge all refrigerant and charge the unit again with right amount.
	3. Inadequate water flow	3. Check the water flow of the system. Use a bigger pump to increase the water flow if necessary.
	4. Too high water temperature	4. Check the value of the water temperature sensor, to ensure it works properly.
Too low suction pressure	1. Drier filter is blocked	1. Change a new one
	2. Electronic expansion valve is not opened	2. Repair or change a new one
	3. Leakage of refrigerant	3. Inspect the unit for leakage and fix it if any. Discharge all refrigerant and charge the unit again with right amount.
Unit can not defrost properly	1. Coil temperature sensor failure	1. Check the position and value of the coil temperature sensor. Replace it if necessary.
	2. Air inlet/outlet is blocked	2. Remove any object that blocks the air circulation of the unit. Clean the evaporator coil occasionally.

Service and maintenance


The following phenomenon may not be problems of unit itself.

Please contact with a professional maintenance staff for help.

Number	Failure	Solution
1	The unit is not running	When the unit restarts, the compressor will start 3 minutes later (self-protection of compressor), please check if the circuit breaker is disconnected, and if there is normal power supply for the wire controller.
2	Low capacity	Check if the air inlet or outlet is blocked in outdoor unit; check if the setting temperature is too high in cooling mode, or too low in heating mode.

Wiring diagram

【Indoor unit】




TAKE CARE!

This diagram is subject to change with improvement of the unit. Always refer to the diagram supplied with the product.

Wiring diagram

【Outdoor unit】



TAKE CARE!

This diagram is subject to change with improvement of the unit. Always refer to the diagram supplied with the product.

